



Original		Recharge		Original		Recharge	
	Power		Power		Vol+ Tv		Vol+
	Power Tv		Shift + Power		Rec		Rec / Rec Mode
	DVD		Shift + 2		0		0
	VCR		Shift + 4		AV Input		AV / Input / RDS
	Eject/Open-Close		Eject / Surround		Vol- Tv		Vol-
	AV Input Tv		Shift + AV / Input / RDS		<< Scan		<< / Tune-
	1		1		Scan >>		>> / Tune+
	2		2		I<< Skip		I<< / Preset-
	3		3		Skip >>I		>>I / Preset+
	PR+ Tv		CH+ / Page+		Pause/Step		Pause / Step / Freeze
	4		4		Play		Play / Slow
	5		5		Stop		Stop / Hold
	6		6		Home		Menu / Home
	PR- Tv		CH- / Page-		PR/TRK+		Shift + CH+ /
	7		7		Up		Up
	8		8		Menu/List		D.Menu / Top
	9		9		Left		Left



