

































	Original	Rechange
	Standby	 Power
	USB	 AV
	1	 1
	2	 2
	3	 3
	4	 4
	5	 5
	6	 6
	7	 7
	8	 8
	9	 9
	0/10	 0
	10+	 Guide
	Time	 +  Shift + AV
	SUB/MP3	 Media
	Angle	 Red
	Audio	 Dual

	Original	Rechange
	Mute	 Mute
	Menu	 Menu
	Setup	 Options
	Title	 TV/R
	L/R	 Green
	Up	 Up
	Down	 Down
	Right	 Right
	Left	 Left
	Enter	 Ok
	<<	 <<
	>>	 >>
	Play	 Play
	Pause	 Pause
	Stop	 Stop
	I<<	 I<<
	>>I	 >>I



