

















































	Original	Rechange		Original	Rechange
	Power		Power		8
	Mute		Mute		9
	Audio		Dual		0
	N/P		Format		10+
	Subtitle		Subt		Setup
	Zoom		Eject		Up
	Angle		Back		Down
	Program		Sleep		Right
	Display		Info		Left
	Step		AV		Enter
	1		1		Repeat
	2		2		AB
	3		3		Menu
	4		4		PBC
	5		5		Stop
	6		6		<<
	7		7		>>



