







































































Original	Rechange	Original	Rechange
 Power	 Power	 Stop	 Stop
 Open/Close	 Eject	 Play	 Play
 1	 1	 I<<	 I<<
 2	 2	 >>I	 >>I
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 OK	 Ok
 8	 8	 Menu DVD	 Menu
 9	 9	 Setup	 Options
 0	 0	 Vol+	 Vol +
 10+	 Guide	 Vol-	 Vol -
 Video Out	 AV	 Mute	 Mute
 <<	 <<	 Language	 Dual
 >>	 >>	 Angle	 TV/R
 Pause	 Pause	 Subtitle	 Subt



