







































































Original		Rechange		Original		Rechange	
	Standby / On		Power		Last PR		Smart / List
	Open / Close		Eject / Surround		0 / A.DUB		0
	1 / ATR TRK -		1		TV / VCR		AV / Input / RDS
	2 / ATR		2		DVD		Shift + 2
	3 / ATR TRK +		3		TV View		TV/Radio /
	Volume +		Vol+		VCR		Shift + 4
	4 / Shuttle <<		4		<<		<< / Tune-
	5 / Shuttle		5		Stop		Stop / Hold
	6 / Shuttle >>		6		Play / Pause		Play / Slow
	Prog +		CH+ / Page+		Play / Pause		Pause / Step / Freeze
	Volume -		Vol-		>>		>> / Tune+
	Prog -		CH- / Page-		I<< / Rec		I<< / Preset-
	7 / SVHS		7		I<< / Rec		Rec / Rec Mode
	8		8		Angle / Timer		Info / Angle
	9		9		Angle / Timer		Sleep / Timer
	Mute		Mute / Dimmer		>>I / Frame/Step		>>I / Preset+
	3D Sound		D.Menu / Top		Zoom / Speed		Zoom / Size





	Original	Rechange	Original	Rechange
	Subtitle	Subtitle / EQ		
	Display	Display / Media		
	Audio	Audio / Lang I/II		
	Setup	Setup / OPT /		
	Up	Up		
	Menu	Menu / Home		
	Left	Left		
	Enter	OK		
	Right	Right		
	Title	Sound / Title		
	Down	Down		
	Clear	Exit / Cancel / Clear		
	Mark / Index	Fav / Marker / PC		
	Return / CLK/CTR	Back / Return		
	A-B / Mode / Repeat	Yellow / YouTube / Repeat		

