



































| Original | Rechange |
|--|---|
|  Power |  Power |
|  Mute |  Mute / Dimmer |
|  P.Mode |  Picture / Format |
|  S.Mode |  Sound / Title |
|  FAV |  Fav / Marker / PC |
|  Sleep |  Sleep / Timer |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  -/- |  Shift + Guide / EPG / -/- |
|  0 |  0 |

| Original | Rechange |
|--|--|
|  Recall |  Back / Return |
|  Vol+ |  Vol+ |
|  CH.List |  Smart / List |
|  CH+ |  CH+ / Page+ |
|  Vol- |  Vol- |
|  Aspect |  Shift + Picture / Format |
|  CH- |  CH- / Page- |
|  EPG |  Guide / EPG / -/- |
|  Audio |  Audio / Lang I/II |
|  Rec |  Rec / Rec Mode |
|  Menu |  Menu / Home |
|  Exit |  Exit / Cancel / Clear |
|  Up |  Up |
|  Left |  Left |
|  Enter |  OK |
|  Right |  Right |
|  Source |  AV / Input / RDS |



