































































































Original		Rechange		Original		Rechange	
	Power		Power		Menu		Menu / Home
	Mute		Mute / Dimmer		Up		Up
	Text / Play/Pause		Play / Slow		Left		Left
	Text / Play/Pause		Pause / Step / Freeze		Enter		OK
	Text / Play/Pause		Text / Goto		Right		Right
	Still / Stop		Stop / Hold		Down		Down
	Radio		TV/Radio /		Info		Info / Angle
	Aspect / Size		Zoom / Size		Exit		Exit / Cancel / Clear
	Red / <<		<< / Tune-		Vol +		Vol+
	Red / <<		Red / Netflix / Search		Index		Display / Media
	Green / >>		Green / APP / Repeat		CH +		CH+ / Page+
	Green / >>		>> / Tune+		Vol -		Vol-
	Yellow / I<<		Yellow / YouTube / Repeat		List		Smart / List
	Yellow / I<<		I<< / Preset-		CH -		CH- / Page-
	Blue / >>I		>>I / Preset+		1		1
	Blue / >>I		Blue / Prime Video / Random		2		2
	Source		AV / Input / RDS		3		3





Original		Rechange		Original		Rechange	
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	Audio / I/II		Audio / Lang I/II				
	0		0				
	DVB		D.Menu / Top				
	FAV		Fav / Marker / PC				
	Sleep		Sleep / Timer				
	EPG		Guide / EPG / -/--				
	Prev. CH.		Back / Return				
	Cancel		Shift + Exit / Cancel / Clear				
	Subtitle		Subtitle / EQ				
	USB		Shift + 8				
	Rec		Rec / Rec Mode				

