



Original	Rechange
Power	Power
VCR	Shift + 2
DVD	Shift + 1
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Input Select	AV
Display / CLK/CNT	Info
Open/Close / Eject	Eject
TV / VCR	TV/R

Original	Rechange
Clear / Count. Reset	Exit
Blank Search	Green
Top Menu	Shift + Menu
Menu	Menu
Return	Back
Zoom	Shift + Eject
Angle	Format
Subtitle	Subt
Audio	Dual
Instant Replay	Shift + Play
Play	Play
<< REW	<<
FWD >>	>>
Slow	Shift + Pause
Stop	Stop
Pause Step / Still	Pause
I<< Skip	I<<





Original		Rechange		Original	Rechange
	Skip >>I		>>I		
	Repeat		Text		
	Marker		Pre Ch		
	i / Set Up / VCR Menu		Options		
	Up / PR/TRK +		Up		
	Up / PR/TRK +		Ch +		
	Down / PR/TRK -		Down		
	Down / PR/TRK -		Ch -		
	Right		Right		
	Left		Left		
	OK / Enter		Ok		
	Auto TRK		Smart		
	A-B RPT / SP/LP		Vol +		
	Random / Inst		Vol -		
	Search		Shift + TV/R		
	Program		Sleep		
	Rec / OTR.		Rec		

