



Original	Recharge
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Source	 AV / Input / RDS
 0	 0
 Info	 Info / Angle
 DMP	 Display / Media
 Up	 Up
 EPG	 Guide / EPG / -/-

Original	Recharge
 Left	 Left
 Enter	 OK
 Right	 Right
 Menu	 Menu / Home
 Down	 Down
 Exit	 Exit / Cancel / Clear
 Vol +	 Vol+
 List	 Smart / List
 CH +	 CH+ / Page+
 Vol -	 Vol-
 CH -	 CH- / Page-
 Fav	 Fav / Marker / PC
 Sleep	 Sleep / Timer
 Index	 D.Menu / Top
 Recall	 Back / Return
 Red / <<	 Red / Netflix / Search
 Red / <<	 Red / << / Tune-





Shift + Sleep / Timer

