








































































Original	Rechange	Original	Rechange
 Power	 Power	 Blue	 Blue
 PREMIUM NET	 Smart	 Back	 Back
 Guida	 Guide	 Exit / Stop	 Exit
 Menu	 Menu	 Exit / Stop	 Stop
 Info	 Info	 << REW	 <<
 Vol +	 Vol +	 >> FWD	 >>
 Vol -	 Vol -	 Pause / Play	 Play
 P +	 Ch +	 Pause / Play	 Pause
 P -	 Ch -	 1	 1
 Up	 Up	 2	 2
 Left	 Left	 3	 3
 OK	 Ok	 4	 4
 Right	 Right	 5	 5
 Down	 Down	 6	 6
 Red	 Red	 7	 7
 Green	 Green	 8	 8
 Yellow	 Yellow	 9	 9




Original
Rechange

	0		0
	Lista		List
	Opzioni		Options
	Text		Text
	TV / Rad		TV/R
	APP		Shift + Media
	Source		AV
	I<< Prev		I<<
	Rec		Rec
	File		Media
	>>I Next		>>I

Original
Rechange

