







































































Original		Rechange		Original		Rechange	
	Standby		Power		Down		Down
	Mute		Mute		Right		Right
	P/N		Smart		Left		Left
	Open/Close		Eject		OK		Ok
	<<		<<		Vol+		Vol +
	>>		>>		Vol-		Vol -
	Play/Pause		Play		1		1
	Stop		Stop		2		2
	I<<		I<<		3		3
	>>I		>>I		4		4
	Setup		Options		5		5
	Source		AV		6		6
	Info		Info		7		7
	Return/Exit		Exit		8		8
	CH+		Ch +		9		9
	CH-		Ch -		0		0
	Up		Up		Slow		Back





Original		Recharge		Original	Recharge
	Goto		Media		
	Program		Sleep		
	Title/TTX		Text		
	Audio		Dual		
	Subtitle		Subt		
	Red/Repeat		Red		
	Green/A-B		Green		
	Yellow/Menu		Yellow		
	Blue/Angle		Blue		
	EPG		Guide		
	Favorite		Pre Ch		
	Tv/Radio		TV/R		
	Zoom		Shift + Eject		

