







































































Original		Rechange		Original		Rechange	
	Power		Power		Vol +		Vol +
	Energy Saving		3D		Vol -		Vol -
	Ratio		Format		FAV / Mark		Pre Ch
	Input		AV		Mute		Mute
	TV/RAD		TV/R		P+ / Page +		Ch +
	Menu		Menu		P- / Page -		Ch -
	Q.Menu		D. Menu		1		1
	Guide		Guide		2		2
	Up		Up		3		3
	Left		Left		4		4
	OK		Ok		5		5
	Right		Right		6		6
	Down		Down		7		7
	Return / Exit		Back		8		8
	Return / Exit		Exit		9		9
	Info		Info		0		0
	AV Mode		Shift + AV		List		List



