



Original	Recharge
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Lang	 Audio / Lang I/II
 0	 0
 TXT	 Text / Goto
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 P-	 CH- / Page-
 Vol-	 Vol-

Original	Recharge
 Source	 AV / Input / RDS
 P+	 CH+ / Page+
 Home	 Menu / Home
 G	 Guide / EPG / -/--
 i	 Info / Angle
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Back	 Back / Return
 Exit	 Exit / Cancel / Clear
 Netflix	 Shift + Red / Netflix /
 YouTube	 Shift + Yellow / YouTube /
 *1	 Picture / Format
 Prime Video	 Shift + Blue / Prime
 Red	 Red / Netflix / Search



[illegible]