







































































Original		Rechange		Original		Rechange	
	Standby		Power		7		7
	Mute		Mute		8		8
	Aspect		Format		9		9
	P.Mode		Shift + Format		0		0
	S.Mode		Shift + Dual		-/--		Shift + Guide
	Nicam/Audio		Dual		Recall		Back
	Sleep		Sleep		Source		AV
	FAV List		Pre Ch		Menu		Menu
	EPG		Guide		Up		Up
	Rec		Rec		Left		Left
	PVR.Menu		D. Menu		Enter		Ok
	1		1		Right		Right
	2		2		Down		Down
	3		3		Vol+		Vol +
	4		4		Vol-		Vol -
	5		5		Exit		Exit
	6		6		Display		Info





Original	Recharge
CH+	Ch +
CH-	Ch -
	Red
	Yellow
	Blue
	Green
	Text
	Smart
	Subt
	Shift + Left
	Shift + Text
	List
	Eject
	Shift + Exit
	Play
	Pause
	Stop

Original	Recharge
Tv/Radio	TV/R
Media	Media

