

















































































Original	Recharge
 Power	 Power
 Mute	 Mute
 TV	 Shift + 1
 Rec	 Shift + 2
 DVD	 Shift + 3
 Radio	 TV/R
 Rec Menu	 D. Menu
 [-]/Timeshift	 Format
 Audio	 Dual
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8

Original	Recharge
 9	 9
 0/AV	 0
 EPG/I.Skip	 Guide
 Assist	 Media
 PIP	 3D
 Text/Disc-M	 Text
 Menu	 Menu
 End	 Exit
 Info	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +
 P-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left










































Original		Recharge		Original		Recharge	
	OK		Ok				
	Red/C-Set		Red				
	Green/SV		Green				
	Yellow/Zoom		Yellow				
	Blue/Marker		Blue				
	<<		<<				
	Play		Play				
	>>		>>				
	Rec		Rec				
	Pause		Pause				
	Stop		Stop				





Original	Recharge
 Power	 Power
 Mute	 Mute
 TV	 Shift + 1
 Rec	 Shift + 2
 DVD	 Shift + 3
 Radio	 TV/R
 Rec Menu	 D. Menu
 [-]/Timeshift	 Format
 Audio	 Dual
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8

Original	Recharge
 9	 9
 0/AV	 0
 EPG/I.Skip	 Guide
 Assist	 Media
 PIP	 3D
 Text/Disc-M	 Text
 Menu	 Menu
 End	 Exit
 Info	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +
 P-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left













































	Original	Recharge	Original	Recharge
	OK	 Ok		
	Red/C-Set	 Red		
	Green/SV	 Green		
	Yellow/Zoom	 Yellow		
	Blue/Marker	 Blue		
	<<	 <<		
	Play	 Play		
	>>	 >>		
	Rec	 Rec		
	Pause	 Pause		
	Stop	 Stop		















Original	Recharge
 Power	 Power
 Mute	 Mute
 Tv	 Shift + 1
 Rec	 Shift + 2
 DVD	 Shift + 3
 Radio	 TV/R
 Rec Menu	 D. Menu
 [-]/Timeshift	 Format
 Audio	 Dual
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8

Original	Recharge
 9	 9
 0/AV	 0
 EPG/I.Skip	 Guide
 Assist	 Media
 PIP	 3D
 Text/Disc-M	 Text
 Menu	 Menu
 End	 Exit
 Info	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +
 P-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left







































Original		Recharge		Original		Recharge	
	OK		Ok				
	Red/C-Set		Red				
	Green/SV		Green				
	Yellow/Zoom		Yellow				
	Blue/Marker		Blue				
	<<		<<				
	Play		Play				
	>>		>>				
	Rec		Rec				
	Pause		Pause				
	Stop		Stop				


























Original	Recharge
 TV	 Shift + 1
 Rec	 Shift + 2
 DVD	 Shift + 3
 Radio	 TV/R
 Power	 Power
 Mute	 Mute
 Rec Menu	 D. Menu
 [-]/Timeshift	 Format
 Audio	 Dual
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8

Original	Recharge
 9	 9
 0/AV	 0
 EPG/I.Skip	 Guide
 Assist	 Media
 PIP	 3D
 Text/Disc-M	 Text
 Menu	 Menu
 End	 Exit
 Info	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +
 P-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





Original		Rechange		Original		Rechange	
	OK		Ok				
	Red/C-Set		Red				
	Green/SV		Green				
	Yellow/Zoom		Yellow				
	Blue/Marker		Blue				
	<<		<<				
	Play		Play				
	>>		>>				
	Rec		Rec				
	Pause		Pause				
	Stop		Stop				

