


























Original	Recharge
AVR/AVC On	Power
AVR/AVC Off	Shift + Power
Power Tv	TV/R
Power VCR	Smart
Power DVD/VDP	Media
PHONO	1
CD	2
DVD/VDP	3
VCR-1	4
VCR-2 / V.AUX	5
TV/DBS	6
MD/Tape Mon	7
Tuner	8
Shift	9
Video Select	0
Input Mode	Guide
Surround Mode	Pre Ch

Original	Recharge
<< Deck-VCR	Shift + <<
< Deck-VCR	Shift + Play
Deck-VCR >	Shift + Pause
Deck-VCR >>	Shift + >>
Stop Deck-VCR	Shift + Stop
CH+	Ch +
CH-	Ch -
Disc Skip+	Blue
Play CD/MD/CDR-DVD/	Play
Stop CD/MD/CDR-DVD/	Stop
Pause CD/MD/CDR-DVD/	Pause
>>I CD/MD/CDR-DVD/	>>I
I<< CD/MD/CDR-DVD/	I<<
>> CD/MD/CDR-DVD/	>>
<< CD/MD/CDR-DVD/	<<
System/Setup	Menu
Surround/Menu	D. Menu

















































Original	Recharge	Original	Recharge
 T.Tone/Return	 Back		
 Status/Display	 Info		
 Up	 Up		
 Down	 Down		
 Right	 Right		
 Left	 Left		
 CH.Select/Select	 Ok		
 Master Volume	 Vol +		
 Master Volum	 Vol -		
 Muting	 Mute		
 Tv Vol+	 Shift + Vol +		
 Tv Vol-	 Shift + Vol -		
 Tv CH+	 Shift + Ch +		
 Tv CH-	 Shift + Ch -		





Original		Recharge		Original		Recharge	
	AVR/AVC On		Power		T.Tone/Return		Back
	AVR/AVC Off	 + 	Shift + Power		Status/Display		Info
	CH+		Ch +		Up		Up
	CH-		Ch -		Down		Down
	Deck-VCR >>		>>		Right		Right
	<< Deck-VCR		<<		Left		Left
	Deck-VCR >	 + 	Shift + Pause		CH.Select/Select		Ok
	Stop Deck-VCR	 + 	Shift + Stop				
	Title		Exit				
	Disc Skip+ CD/MD/CDR-DVD/		Blue				
	Play CD/MD/CDR-DVD/		Play				
	Pause CD/MD/CDR-DVD/		Pause				
	Stop CD/MD/CDR-DVD/		Stop				
	CD/MD/CDR-DVD/ VDP >>I		>>I				
	I<< CD/MD/CDR-DVD/		I<<				
	System/Setup		Menu				
	Surround/Menu		D. Menu				

