

































































































Original	Recharge
 Power	 Power
 Red	 Red / Netflix / Search
 Mute	 Mute / Dimmer
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Sleep	 Sleep / Timer
 NR	 Exit / Cancel / Clear
 Auto	 Display / Media
 Recall	 Back / Return
 Add	 Shift + TV/Radio / Program
 Dual	 Audio / Lang I/II
 Text	 Text / Goto
 Input	 AV / Input / RDS
 Up	 Up
 CH+	 CH+ / Page+
 Down	 Down

Original	Recharge
 CH-	 CH- / Page-
 Right	 Right
 Left	 Left
 Vol-	 Vol-
 Menu	 Menu / Home
 OK	 OK
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 +100	 Guide / EPG / -/-
 0	 0





Original	Recharge
 Last	 Shift + Back / Return
 P.STD	 Smart / List
 S.STD	 Eject / Surround
 ARC	 Stop / Hold
 Still	 Pause / Step / Freeze
 Zoom-	 Zoom / Size
 Zoom+	 Setup / OPT /
 Multi-PiP	 TV/Radio /
 Size	 Shift + Zoom /
 S.Swap	 Subtitle / EQ
 Win-Sel	 D.Menu / Top
 Locate	 Sound / Title
 Swap	 Picture / Format

Original	Recharge

