





































Original	Rechange
 Energy/Saving	 Eject / Surround
 Power	 Power
 TV/Rad	 TV/Radio /
 Guide	 Guide / EPG / -/--
 Info	 Info / Angle
 Ratio	 Picture / Format
 Input	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 List	 Smart / List

Original	Rechange
 0	 0
 Q.View	 Display / Media
 Settings	 Menu / Home
 Up	 Up
 Q.Menu	 D.Menu / Top
 Left	 Left
 OK	 OK
 Right	 Right
 Back	 Back / Return
 Down	 Down
 Exit	 Exit / Cancel / Clear
 Vol+	 Vol+
 FAV	 Fav / Marker / PC
 P+	 CH+ / Page+
 Vol-	 Vol-
 Simplink	 Sound / Title
 P-	 CH- / Page-





Original	Recharge	Original	Recharge
Mute	Mute / Dimmer		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Stop	Stop / Hold		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
Subtitle	Subtitle / EQ		
<<	<< / Tune-		
>>	>> / Tune+		
Text	Text / Goto		
T.Opt	Setup / OPT /		

