







































































Original		Rechange		Original		Rechange	
	Power		Power		DVB Menu		Media
	Mute		Mute		CH+		Ch +
	1		1		CH-		Ch -
	2		2		Menu		Menu
	3		3		Back		Back
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		OK		Ok
	9		9		AV/Tv		AV
	0		0		EPG		Guide
	-/--		Shift + Guide		SUBT		Subt
	Recall		Pre Ch		i/Info		Info
	Vol+		Vol +		[≡]/Text		Text
	Vol-		Vol -		[≡+]/Hold		Dual
	Nicam		Smart		[▼]/PGDN		<<





	Original	Recharge		
	[▲]PGUP		>>	
	[≡i]/Index		Exit	
	[≡◆]/Size		Format	
	[≡?]/Reveal		TV/R	
	[≡o]/Subpage		D. Menu	
	Red		Red	
	Green		Green	
	Yellow		Yellow	
	Cyan		Blue	
	Sleep		Sleep	
	FAV	 + 	Shift + Pre Ch	
	Last		Eject	
	P-Mode		3D	

	Original	Recharge		

