






















































	Original	Recharge		Original	Recharge
	Power		Power		0
	Up		Up		PP
	Down		Down		-/--
	Right		Right		P<P
	Left		Left		CH-
	OK/Select		Ok		CH+
	Menu		Menu		Vol+
	[i]/Info		Info		Vol-
	1		1		Mute
	2		2		I-II
	3		3		DTV/TV
	4		4		AV
	5		5		Red/Sound/▲
	6		6		Green/Picture/▼
	7		7		Yellow/Feature
	8		8		Blue/Install
	9		9		[≡]/Text



