







































































Original	Rechange
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 DTV/ATV	 Info
 Recall	 Pre Ch
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 Sleep	 Sleep

Original	Rechange
 Menu	 Menu
 Source	 AV
 Enter	 Ok
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Exit	 Exit
 Display	 Shift + Info
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 MTS	 Shift + Sleep
 Rec List	 D. Menu
 FAV/List	 Dual
 Rec	 Rec





	Original	Recharge
	Freeze	 Options
	<</Guide	 <<
	>>/Aspect	 >>
	I<</Cancel	 +  Shift + Subt
	>>I/Sub.Pg	 Back
	Stop/Index	 Stop
	Play/Pause/Time Shift	 Play
	Tv/Radio	 TV/R
	Subtitle	 Subt
	Reveal	 +  Shift + Options
	Size	 Format
	Hold	 Eject
	Text	 Text
	Red	 Red
	Green	 Green
	Yellow	 Yellow
	Cyan	 Blue

	Original	Recharge

