



















































































Original		Rechange		Original		Rechange	
	Power		Power		Down/CH-		Down
	Mute		Mute		Vol+		Vol +
	1		1		Right		Right
	2		2		Left		Left
	3		3		Vol-		Vol -
	4		4		OK		Ok
	5		5		Exit		Exit
	6		6		Audio		Dual
	7		7		Red		Red
	8		8		Menu		Menu
	9		9		PgUp		Ch +
	0		0		PgDn		Ch -
	SAT		Smart		FAV		Pre Ch
	Zoom		Eject		EPG		Guide
	FAV+		>>I		Tv/Radio		TV/R
	FAV-		I<<		Green		Green
	Up/CH+		Up		Recall		Back









































































Original	Rechange
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SAT	 Smart
 Zoom	 Eject
 FAV+	 >>I
 FAV-	 I<<
 Up/CH+	 Up

Original	Rechange
 Down/CH-	 Down
 Vol+	 Vol +
 Right	 Right
 Left	 Left
 Vol-	 Vol -
 OK	 Ok
 Exit	 Exit
 Audio	 Dual
 Menu	 Menu
 Red	 Red
 PgUp	 Ch +
 PgDn	 Ch -
 FAV	 Pre Ch
 EPG	 Guide
 Tv/Radio	 TV/R
 Green	 Green
 Recall	 Back





Original	Rechange	Original	Rechange
 Power	 Power	 Down/CH-	 Down
 Mute	 Mute	 Right	 Right
 1	 1	 Vol+	 Vol +
 2	 2	 Vol-	 Vol -
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Exit	 Exit
 6	 6	 Audio	 Dual
 7	 7	 Red	 Red
 8	 8	 Menu	 Menu
 9	 9	 PgUp	 Ch +
 0	 0	 PgDn	 Ch -
 SAT	 Smart	 FAV	 Pre Ch
 Zoom	 Eject	 EPG	 Guide
 FAV+	 >>I	 Tv/Radio	 TV/R
 FAV-	 I<<	 Green	 Green
 Up/CH+	 Up	 Recall	 Back



