
















































Original	Recharge
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 FAV/ZAPP	 Pre Ch
 TXT	 Text
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue

Original	Recharge
 Exit/TV-G	 Exit
 ?	 Smart
 @	 Media
 Menu/i	 Menu
 Back	 Back
 Tools	 Options
 Guide	 Guide
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Vol+	 Vol +
 Vol-	 Vol -
 PR+	 Ch +
 PR-	 Ch -
 AV	 AV





	Original	Rechange	Original	Rechange
	Mute	 Mute		
	I<	 I<<		
	>I	 >>I		
	<<	 <<		
	>>	 >>		
	Rec	 Rec		
	Play	 Play		
	Pause	 Pause		
	Stop	 Stop		
	3D/Search	 Format		
	..O/Audio	 Dual		
	[...].	 Subt		
	PIP/ECO	 3D		
	My Media/CEC	 TV/R		

