




































Original	Recharge
 Power	 Power
 [i+]	 Info
 DTT/TV	 TV/R
 AV1	 Shift + 1
 AV2	 Shift + 2
 AV3	 Shift + 3
 AV4	 Shift + 4
 AV5	 Shift + 5
 RGB1	 Shift + 7
 RGB2	 Shift + 8
 Menu	 Menu
 Back	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok

Original	Recharge
 ♪ / S.Mode	 Shift + Dual
 ⏪ / P.Mode	 Shift + Format
 Vol+	 Vol +
 Vol-	 Vol -
 I/II	 Dual
 Mute	 Mute
 P+	 Ch +
 P-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

































Original		Rechange		Original		Rechange	
	0		0				
	2-4-12 / []< >		3D				
	[]≡		Options				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	[]≡i		List				
	[]≡X		Smart				
	[...]/Slide Show		Subt				
	[]≡?/Rotate		Pre Ch				
	[]≡		Text				
	Swivel		Sleep				
	[]<>		Format				
	Photo		Media				













































	Original	Recharge	Original	Recharge
	Power			
	OK			
	Up			
	Down			
	Right			
	Left			
	Menu			
	Play			
	Stop			
	Pause			
	<<			
	>>			
	P+			
	P-			





Original		Rechange		Original		Rechange	
	Power		Power		8		8
	OK		Ok		9		9
	Up		Up		0		0
	Down		Down				
	Right		Right				
	Left		Left				
	P+		Ch +				
	P-		Ch -				
	Vol+		Vol +				
	Vol-		Vol -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				

