

















































Original	Recharge	Original	Recharge
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 Smart	Menu Off	 Exit
Reveal	 Media	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Shift + Info	6	 6
Menu Left	 Left	7	 7



Original	Recharge	Original	Recharge
8	 8	Rotate Pip	 +  Shift + 3
9	 9	Still	 +  Shift + 4
Guide -/-- 1.	 GUIDE	Dim Pip	 +  Shift + 5
0/10	 0	Help	 +  Shift + 6
2.Fav P/C 2.	 PRE-CH		
Red	 A		
Green	 B		
Yellow	 C		
Blue	 D		
Color+ P.Std	 PICTURE FORMAT		
Bright- Sys	 SETTINGS OPT		
AV 2	 SHIFT +  TIMER AV		
Color- S.Std	 SHIFT +  SOUND DUAL		
Contrast+	 SHIFT +  + CH		
Contrast-	 SHIFT +  CH -		
On Pip	 SHIFT +  1		
Swap	 SHIFT +  2		

