





































Original	Rechange
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 ASPECT	 Format
 P.C.	 Pre Ch
 MENU	 Menu
 SOURCE	 Shift + AV
 Up	 Up

Original	Rechange
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Exit	 Exit
 Display	 Info
 Vol +	 Vol +
 Vol -	 Vol -
 CH +	 Ch +
 CH -	 Ch -
 Sound	 Dual
 PIC	 Shift + Format
 NICAM	 Media
 SLEEP	 Sleep
 TV	 Smart
 AV	 AV
 HDMI	 Shift + Media





	Original		Recharge	
	SCART1		Subt	
	Y.PB.PR	 + 	Shift + Subt	
	RECALL		Back	
	Red		Red	
	Green		Green	
	Yellow		Yellow	
	Blue		Blue	
	Reveal		Play	
	Hold		Pause	
	List		List	
	Index		Stop	
	Subpage		Rec	
	Size		3D	
	Auto		Guide	
	Text		Text	

	Original		Recharge	

