





































| Original | Rechange |
|--|--|
|  Power |  Power |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  ASPECT |  Format |
|  P.C. |  Pre Ch |
|  MENU |  Menu |
|  SOURCE |  Shift + AV |
|  Up |  Up |

| Original | Rechange |
|---|--|
|  Right |  Right |
|  Down |  Down |
|  Left |  Left |
|  OK |  Ok |
|  Exit |  Exit |
|  Display |  Info |
|  Vol + |  Vol + |
|  Vol - |  Vol - |
|  CH + |  Ch + |
|  CH - |  Ch - |
|  Sound |  Dual |
|  PIC |  Shift + Format |
|  NICAM |  Media |
|  SLEEP |  Sleep |
|  TV |  Smart |
|  AV |  AV |
|  HDMI |  Shift + Media |



