





































Original	Rechange
 Power	 Power
 Tv/Rad	 TV/R
 Subtitle	 Subt
 AD/PIP/*	 Dual
 TV/PC	 Smart
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List

Original	Rechange
 Q.View	 D. Menu
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Guide	 Guide
 FAV	 Pre Ch
 P+	 Ch +
 P-	 Ch -
 Text	 Text
 Info	 Info
 T.Opt	 Options
 Settings	 Shift + Options
 Q.Menu	 Menu
 Back	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down





Original	Recharge
Right	Right
Left	Left
OK	Ok
Simplink	Format
Rec/*	Rec
Stop	Stop
<<	<<
Play	Play
Pause	Pause
>>	>>
Red	Red
Green	Green
Yellow/Brightness	Yellow
Blue/Brightness+	Blue

Original	Recharge

