

























Original	Recharge	Original	Recharge
 Power	 Power	 Exit	 Exit
 Mute	 Mute	 Display	 Shift + Info
 1	 1	 Enter	 Ok
 2	 2	 Up	 Up
 3	 3	 Down	 Down
 4	 4	 Left	 Left
 5	 5	 Right	 Right
 6	 6	 Vol+	 Vol +
 7	 7	 Vol-	 Vol -
 8	 8	 CH+	 Ch +
 9	 9	 CH-	 Ch -
 0	 0	 FAV/List	 Dual
 Recall	 Pre Ch	 Freeze	 Options
 Source	 AV	 Tv/Radio	 TV/R
 Menu	 Menu	 Rec	 Rec
 P.Mode	 Shift + Format	 Red	 Red
 S.Mode	 Shift + Dual	 Green	 Green





Original	Recharge
Yellow	Yellow
Cyan	Blue
<</Guide	<<
>>/Aspect	>>
I<</Cancel	+  SUBT Shift + Subt
>>I/Sub.Pg	BACK Back
Stop/Index	Stop
Play/Pause/Time Shift	Play
Subtitle	SUBT Subt
Text	TEXT Text
Reveal	+  OPT Shift + Options
Size	FORMAT Format
Hold	Eject
DTV/ATV	INFO Info
Rec List	D.MENU D. Menu
Sleep	SLEEP Sleep
MTS	+  SLEEP Shift + Sleep

Original	Recharge

