





































| Original | Recharge |
|---|---|
|  Power |  Power |
|  Red/↑ |  Red / Netflix / Search |
|  Green/↓ |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  M |  Menu / Home |
|  Return |  Back / Return |
|  Up |  Up |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Down |  Down |
|  Source |  AV / Input / RDS |
|  Presets |  D.Menu / Top |
|  Info |  Info / Angle |
|  EPG |  Guide / EPG / -/- |
|  Vol+ |  Vol+ |

| Original | Recharge |
|--|---|
|  Mute |  Mute / Dimmer |
|  P+ |  CH+ / Page+ |
|  Vol- |  Vol- |
|  P- |  CH- / Page- |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  FAV |  Shift + Fav / Marker / PC |
|  0 |  0 |
|  Recall |  Fav / Marker / PC |
|  Screen |  Picture / Format |





| Original | Recharge | Original | Recharge |
|--|---|----------|----------|
|  Lang |  Audio / Lang I/II | | |
|  Subtitle |  Subtitle / EQ | | |
|  Sleep |  Sleep / Timer | | |
|  (O) |  Display / Media | | |
|  O/World |  Smart / List | | |
|  [≡x] |  TV/Radio / | | |
|  [≡] |  Text / Goto | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

