







































































	Original	Recharge		Original	Recharge
	 Power	 Power		 Right / Vol +	 Vol +
	 SUB-T	 Subt		 Left / Vol -	 Left
	 Lang	 Dual		 Left / Vol -	 Vol -
	 Mute	 Mute		 OK	 Ok
	 EPG	 Guide		 FAV	 Pre Ch
	 Goto	 Smart		 TV / Radio	 TV/R
	 Page +	 Shift + Ch +		 Recall	 Back
	 Page -	 Shift + Ch -		 Info	 Info
	 TTX	 Text		 1	 1
	 Repeat	 Shift + Text		 2	 2
	 Menu	 Menu		 3	 3
	 Exit	 Exit		 4	 4
	 Up / CH +	 Up		 5	 5
	 Up / CH +	 Ch +		 6	 6
	 Down / CH -	 Down		 7	 7
	 Down / CH -	 Ch -		 8	 8
	 Right / Vol +	 Right		 9	 9









































































Original		Recharge		Original		Recharge	
	0		0				
	<<		<<				
	>>		>>				
	<<		<<				
	>>		>>				
	Play		Play				
	Pause / Timeshift		Pause				
	Stop		Stop				
	Rec		Rec				
	Red / PVR		Red				
	Green / V-Format		Green				
	Green / V-Format		Format				
	Yellow / Aspect		Yellow				
	Yellow / Aspect		3D				
	Blue / Timer		Blue				





Original		Rechange		Original		Rechange	
	Power		Power		OK		Ok
	Mute		Mute		FAV		Pre Ch
	EPG		Guide		TV / Radio		TV/R
	Info		Info		Text		Text
	Audio		Dual		Goto		Smart
	Recall		Back		1		1
	Subtitle		Subt		2		2
	Menu		Menu		3		3
	Exit		Exit		4		4
	Up / CH +		Up		5		5
	Up / CH +		Ch +		6		6
	Down / CH -		Down		7		7
	Down / CH -		Ch -		8		8
	Right / Vol +		Right		9		9
	Right / Vol +		Vol +		0		0
	Left / Vol -		Left		USB		Media
	Left / Vol -		Vol -		Rec		Rec





Original		Rechange		Original		Rechange	
	Stop		Stop				
	Play / Pause		Play				
	Play / Pause		Pause				
	<<		<<				
	>>		>>				
	I<<		I<<				
	>>I		>>I				
	---	+	Shift + 1				
	---	+	Shift + 2				
	---	+	Shift + 3				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

