





























Original	Recharge
 Power	 Power
 Source	 AV
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 PR+	 Ch +
 PR-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Recharge
 TV	 TV/R
 Recall	 Pre Ch
 World	 Media
 Menu	 Menu
 Exit	 Exit
 Back	 Back
 i/Info	 Info
 Guide	 Guide
 [≡]/Text	 Text
 */O	 Format
 */O..	 3D
 Lang	 Dual
 [≡]..	 Subt
 [-O-]	 Options
 Red	 Red
 Green	 Green
 Yellow	 Yellow





	Original	Rechange	Original	Rechange
	Blue	 D		Blue
	Rec	 REC MODE		Rec
	Play	 PLAY MODE		Play
	Stop			Stop
	Pause			Pause
	<<			<<
	>>			>>
	OK			Ok
	Up			Up
	Down			Down
	Right			Right
	Left			Left
	Music/Photo/Movi	 HOME SMART		Smart
	Q.Menu	 E-MANUAL D.MENU		D. Menu

