







































































	Original	Rechange		Original	Rechange
	Power		Power		7
	[ + ]		Info		8
	Tv/AV		AV		9
	Mute		Mute		0
	^		Ch +		-/--
	v		Ch -		Timer
	Vol+		Vol +		N
	Vol-		Vol -		Menu
	V		Ok		Mood Light
	V+		Right		Red
	V-		Left		Green
	1		1		Yellow
	2		2		Blue
	3		3		Power VCR
	4		4		Audio Out VCR
	5		5		^ VCR
	6		6		v VCR
					7
					8
					9
					0
					Guide
					Shift + AV
					Media
					Menu
					Format
					Red
					Green
					Yellow
					Blue
					Shift + Power
					Dual
					Up
					Down



