







































































Original		Rechange		Original		Rechange	
	Operate		Power		C/Eraser		3D
	Open/Close		Eject		ShowView		Format
	1		1		HDD		Smart
	2		2		DVD		Media
	3		3		Input		AV
	4		4		Start Menu		Menu
	5		5		DVD Menu/Original		Shift + Menu
	6		6		Return		Back
	7		7		Exit		Exit
	8		8		DVD Title/Rec List		D. Menu
	9		9		SET/Enter		Ok
	0		0		Up		Up
	-/--		Guide		Down		Down
	Tv/DVD		TV/R		Right		Right
	CH+		Ch +		Left		Left
	CH-		Ch -		Dubbing		List
	Direct		Options		P IN P		Text





Original	Rechange	Original	Rechange
Timer On/Off	Shift + AV	Replay	Shift + Play
Timeshift	Shift + Guide	Skip Search	Shift + TV/R
Blue/A-B	Blue	Zoom/Rec Mode	Shift + Rec
Red/B	Red	Function	Shift + D. Menu
Green/C	Green	Audio	Dual
Yellow/D	Yellow	Angle	Shift + Red
Play	Play	Subtitle	Subt
<</REV	<<	Direct Rec Tv	Shift + Text
>>/FWD	>>	Tamper Proof/On Screen	Shift + Format
Stop/Live	Stop	RGB Off/Chapter Mark	Shift + Pre Ch
Still/Pause	Pause	Operate Tv	Shift + Power
I>/Slow	Sleep	Back	Info
Rec	Rec	Vol+ Tv Control	Vol +
Stop Rec	Shift + Stop	Vol- Tv Control	Vol -
Pause Rec	Shift + Pause	CH+ Tv Control	Shift + Ch +
>>I/F.ADV Skip	>>I	CH- Tv Control	Shift + Ch -
I<</I F.ADV	I<<	Input Tv Control	Pre Ch

