







































































Original		Recharge		Original		Recharge	
	Power		Power		Menu/Set		MENU
	Mute		MUTE		V.Size		V-FOR
	Tv/Video		SRC		MTS		MEDIA
	Sleep		VOD		Sound		Audio
	◆ Bright		-/-- / EPG		Picture		Subt.
	PIP		WIDE		1		1
	Exit		EXIT		2		2
	Text		TEXT		3		3
	Pre PG		P/C / FAV		4		4
	Up		UP		5		5
	Down		DOWN		6		6
	Right		RIGHT		7		7
	Left		LEFT		8		8
	PG+		CH +		9		9
	PG-		CH -		0		0
	Vol+		VOL +		Time		TV/R
	Vol-		VOL -		Still		OPT+



