





































Original	Rechange
	 Power
	 3D
	 TV/R
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 Shift + 3D
	 AV
	 Vol +
	 Vol -

Original	Rechange
	 Mute
	 Ch +
	 Ch -
	 Info
	 Options
	 Smart
	 Guide
	 Menu
	 Back
	 Up
	 Down
	 Right
	 Left
	 Ok
	 Exit
	 Media
	 Shift + Ch -



