





































































Original	Rechange
 Power	 Power
 Open/Close	 Eject
 Prog+	 Ch +
 Prog-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--/Clear	 GUIDE

Original	Rechange
 Set	 D. Menu
 O))	 Dual
 [...]	 Subt
 Camera	 Green
 Input/Tv/DVD	 TV/R
 Timer	 AV
 Display	 Info
 Time/Text	 Text
 [+]	 Format
 System Menu	 Media
 Tools	 Options
 Title List	 List
 Cursor Mode	 Exit
 Return	 Back
 Zoom+	 Blue
 Zoom-	 Yellow
 Up	 Up






Original	Recharge
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Top Menu	 Shift + Menu
 Menu	 Menu
 →	 Shift + Ch +
 ←	 Shift + Ch -
  >/>>	 >>
 <</<	 <<
 >>	 >>
  <<	  <<
 ▷	 Play
	 Pause
 ■	 Stop
 REC DVD1	 Rec
 REC PAUSE	 Shift + Pause



Original	Recharge
 Synchro Rec	 Shift + 1
 Rec Stop DVD1	 Shift + Stop
 Mode Rec DVD1	 Shift + Format
 Chapter Mark	 Smart
 Input Select DVD1	 Shift + AV
 Mark Erase	 Shift + Media
 Progressive DVD1	 Sleep
 Sur DVD1	 Shift + Text
 Rec DVD2	 Shift + Rec
 Rec Pause	 Shift + 2
 Rec Stop DVD2	 Shift + 3
 Rec Mode DVD2	 Shift + 4
 Input Select DVD2	 Shift + 5
 Chapter Mark	 Shift + 6
 Mark Erase	 Shift + 7
 Synchro Rec	 Shift + 8
 Progressive DVD2	 Shift + Sleep



DVD1







































Original	Recharge
 Sur DVD2	 Shift + 9

Original	Recharge






Original	Recharge
 Power	 Power
 Open/Close	 Eject
 Prog+	 Ch +
 Prog-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--/Clear	 GUIDE Guide

Original	Recharge
 Set	 D. Menu
 O))	 Dual
 [...]	 Subt
 Camera	 Green
 Input/Tv/DVD	 TV/R
 Timer	 AV
 Display	 Info
 Time/Text	 Text
 [+]	 Format
 System Menu	 Media
 Title List	 List
 Tools	 Options
 Cursor Mode	 Exit
 Zoom+	 Blue
 Zoom-	 Yellow
 Return	 Back
 Up	 Up







Original	Recharge
	Down
	Right
	Left
	Ok
	Shift + Menu
	Menu
	Shift + Ch +
	Shift + Ch -
	>>>
	<<<
	>>
	<<<
	<<<
	Play
	Pause
	Stop
	Rec DVD3
	Rec
	Shift + Pause

Original	Recharge
	Shift + Stop
	Shift + Rec
	3D
	Smart
	Shift + Media
	Sleep
	Pre Ch
	Shift + Text



DVD3