

















































Original		Recharge		Original		Recharge	
	Power		Power		0		0
	[=]		Text / Goto		Red		Red / Netflix / Search
	Enter		OK		Green		Green / APP / Repeat
	Vol+		Vol+		Yellow		Yellow / YouTube / Repeat
	Prog+		CH+ / Page+		Blue		Blue / Prime Video / Random
	Vol-		Vol-		Repeat		Shift + Green / APP /
	Prog-		CH- / Page-				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	-/--		Guide / EPG / -/--				





Original	Recharge
Open/Close	Eject / Surround
Display	Display / Media
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Wide Mode	Zoom / Size
Tv/Video	TV/Radio /
-/--/Search Mode	Guide / EPG / -/--
0	0
Clear	Exit / Cancel / Clear

Original	Recharge
Time	Sleep / Timer
Red/Shuffle	Red / Netflix / Search
Green/Program	Green / APP / Repeat
Repeat	Shift + Green / APP /
A-B	Shift + Yellow / YouTube /
Yellow/Audio	Yellow / YouTube / Repeat
Blue/Angle	Blue / Prime Video / Random
[=]/Subtitle	Text / Goto
Subtitle On/Off	Subtitle / EQ
AV Center	AV / Input / RDS
<   Step	Shift + Left
Step   >	Shift + Right
<  Slow	CH- / Page-
Slow  >	CH+ / Page+
AV Vol+	Vol+
I<</Prev	I<< / Preset-
>>I/Next	>>I / Preset+







Original	Recharge
<< Scan	<< / Tune-
>> Scan	>> / Tune+
AV Vol-	Vol-
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Set Up	Setup / OPT /
Title	Sound / Title
DVD Menu	D.Menu / Top
Return	Back / Return
Tv/DVD	+  Shift + TV/Radio / Program
Up	Up
Left	Left
Enter	OK
Right	Right
Down	Down

Original	Recharge

