













































Original	Rechange
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Reset	 Guide / EPG / -/--
 0 / AV PC	 0
 RTN	 Back / Return
 Display	 Display / Media
 Up / P+	 Up
 Up / P+	 CH+ / Page+
 Input	 AV / Input / RDS

Original	Rechange
 Left / V-	 Left
 Left / V-	 Vol-
 Menu / Enter	 Menu / Home
 Menu / Enter	 OK
 Right / V+	 Right
 Right / V+	 Vol+
 ARC	 Info / Angle
 Down / P-	 Down
 Down / P-	 CH- / Page-
 Exit	 Exit / Cancel / Clear
 Text	 Text / Goto
 Text Subcode	 Subtitle / EQ
 PIP Up	 Shift + Up
 PIP Position	 Shift + Left
 PIP On/Off	 Shift + OK
 PIP Size	 Shift + Right
PIP Down	Shift + Down





Original		Rechange		Original		Rechange	
	Text Reveal		Play / Slow				
	Text Index		Smart / List				
	Text Hold		Stop / Hold				
	Text Cancel		Rec / Rec Mode				
	Text Size		Zoom / Size				
	Green / MUP		Green / APP / Repeat				
	Yellow / Pause		Yellow / YouTube / Repeat				
	Yellow / Pause		Pause / Step / Freeze				
	Blue / Audio		Blue / Prime Video / Random				
	Blue / Audio		Audio / Lang I/II				
	Red / Picture		Red / Netflix / Search				
	Red / Picture		Setup / OPT /				
	Sleep		Sleep / Timer				
	Mute		Mute / Dimmer				

