


















Original	Rechange
 Power	 Power
 Sleep	 Sleep / Timer
 Program	 TV/Radio /
 Cancel	 Exit / Cancel / Clear
 1	 1
 2	 2
 3	 3
 Disc	 Fav / Marker / PC
 4	 4
 5	 5
 6	 6
 >=10 / -/-	 Guide / EPG / -/-
 7	 7
 8	 8
 9	 9
 0	 0
 Test	 Text / Goto

Original	Rechange
 Pro Logic	 Audio / Lang I/II
 Super SRND	 Eject / Surround
 Super 3D AI EQ	 Menu / Home
 Up	 Up
 Left	 Left
 EQ	 Subtitle / EQ
 EQ	 OK
 Right	 Right
 CH Select	 Smart / List
 Down	 Down
 AV Effect	 AV / Input / RDS
 Super Sound EQ	 Sound / Title
 Digital S. Woofer	 Setup / OPT /
 VCR / AUX / 6CH Input	 Shift + 7
 VCR / AUX / 6CH Input	 Shift + 4
 VCR / AUX / 6CH Input	 Red / Netflix / Search
 TAPE / Deck 1/2	 Shift + 5



