







































































	Original	Rechange	Original	Rechange
	Power			Sleep
	Mute			Jump
	Source			FAV.CH
	I/II/Audio			Ok
	1			Up
	2			Down
	3			Left
	4			Right
	5			Vol+
	6			Vol-
	7			PR-
	8			PR+
	9			Red/D.Setup
	0			Green/Repeat
	Menu			Yellow/Zoom
	Info			Blue/Goto
	Exit			[≡+]/DTV/Radio
				Sleep
				Media
				Pre Ch
				Ok
				Up
				Down
				Left
				Right
				Vol +
				Vol -
				Ch -
				Ch +
				Red
				Green
				Yellow
				Blue
				TV/R





	Original	Rechange	Original	Rechange
	[≡♦]/USB/SD	Options		Format
	[≡?]/Timeshift	Pause		
	[≡i]/PVR List	3D		
	Rec	Rec		
	Stop	Stop		
	Play/Pause	Play		
	<<<	<<<		
	>>>	>>>		
	<<<	<<<		
	>>>	>>>		
	DVD Menu	D. Menu		
	Text	Text		
	Subtitle	Subt		
	Guide	Guide		
	Eject	Eject		
	P.Mode	Shift + Format		
	S.Mode	Shift + Dual		

