| Original | Rechange |
|---|---|
| Power | Power |
| Mute | Mute / Dimmer |
| Play | Play / Slow |
| Pause | Pause / Step / Freeze |
| Stop | Stop / Hold |
| Rec | Rec / Rec Mode |
| << | << / Tune- |
| >> | >> / Tune+ |
| Lang | Audio / Lang I/II |
| Source (Games) | Eject / Surround |
| Movie-Music-Phot | Picture / Format |
| [≡].. | Zoom / Size |
| */O | Sleep / Timer |
| TV | TV/Radio / |
| Q.Menu | D.Menu / Top |
| [-O-] | Setup / OPT / |
| [≡]/Text | Text / Goto |

| Original | Rechange |
|---|---|
| Menu | Menu / Home |
| Up | Up |
| i | Info / Angle |
| Left | Left |
| OK | OK |
| Right | Right |
| Exit | Exit / Cancel / Clear |
| Down | Down |
| Back | Back / Return |
| Vol+ | Vol+ |
| World (Violet) | Smart / List |
| PR+ | CH+ / Page+ |
| Vol- | Vol- |
| */Q | Display / Media |
| PR- | CH- / Page- |
| 1 | 1 |
| 2 | 2 |

| Original | | Rechange | |
|---|---|---|---|
| 3 def | 3 | CD - STB 3 | 3 |
| 4 ghi | 4 | VIDEO 4 | 4 |
| 5 jkl | 5 | TAPE 5 | 5 |
| 6 mno | 6 | TUNER 6 | 6 |
| 7 pqrs | 7 | AUX - HDD 7 | 7 |
| 8 tuv | 8 | USB 8 | 8 |
| 9 wxyz | 9 | BLUETOOTH 9 | 9 |
| | Guide | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 | HDMI - SAT 0 | 0 |
| | Red | NETFLIX SEARCH | Red / Netflix / Search |
| | Green | APP REPEAT | Green / APP / Repeat |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random |
| | Recall | SHIFT + RETURN BACK | Shift + Back / Return |

| Original | Rechange |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |