Original		Rechange		Original		Rechange	
POWER	Power		Power		Left		Left
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	ENTER	Enter	OK	OK
PLAY/PAUSE	Play/Pause	SLOW	Play / Slow		Right		Right
STOP	Stop	HOLD	Stop / Hold	EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
REC	Rec	REC MODE	Rec / Rec Mode		Down		Down
REW	<</REW	TUNE-	<< / Tune-	RECALL	Recall	RETURN BACK	Back / Return
FF	>>/FF	TUNE+	>> / Tune+	VOL+	Vol +	VOL +	Vol +
PREV	I<</Prev	PRESET-	I<< / Preset-	PAGEUP	Page Up	CH PAGE +	CH+ / Page+
NEXT	>>I/Next	PRESET+	>>I / Preset+	VOL-	Vol -	VOL -	Vol -
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II	PAGEDN	Page Dn	CH PAGE -	CH- / Page-
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ	1	1	TV 1	1
TV/RADIO /MMB	Tv/Radio/MMB	PROGRAM TV/RADIO	TV/Radio /	2	2	DVD 2	2
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /	3	3	CD-STB 3	3
TTX	TTX	GOTO TEXT	Text / Goto	4	4	VIDEO 4	4
MENU	Menu	HOME MENU	Menu / Home	5	5	TAPE 5	5
	Up		Up	6	6	TUNER 6	6
INFO	Info	ANGLE INFO	Info / Angle	7	7	AUX-HDD 7	7

Original		Rechange		Original	Rechange
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
FAV	FAV	PC FAV MARKER	Fav / Marker / PC		
Red		NETFLIX SEARCH	Red / Netflix / Search		
Green		APP REPEAT	Green / APP / Repeat		
Yellow		YouTube REPEAT A-B	Yellow / YouTube / Repeat		
Blue		Prime Video RANDOM	Blue / Prime Video / Random		
../.. GOTO	-/--/Goto	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--		