Original		Rechange	
	Power		Power
	HDMI Control	HOME SMART	Smart
	Rec	REC MODE	Rec
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	I<<		I<<
	<<		<<
	>>		>>
	>>I		>>I
SCREEN	Screen	PICTURE FORMAT	Format
LANG	Lang	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
	PIP / World	ECO 3D	3D
ZOOM	Red / Zoom	A	Red
REPEAT	Green / Repeat	B	Green
ROOT	Yellow / Root	C	Yellow

Original		Rechange	
TITLE	Blue / Title	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TEXT	Text	REPEAT TEXT	Text
SWAP	Swap	FAV PRE-CH	Pre Ch
	Up		Up
	Right		Right
	Down		Down
	Left		Left

Original		Rechange		Original	Rechange
OK	OK	OK	Ok		
P/CH +	P/CH +	+ CH	Ch +		
P/CH -	P/CH -	CH −	Ch -		
Mute	Mute	MUTE	Mute		
Vol +	Vol +	+ VOL	Vol +		
Vol -	Vol -	VOL −	Vol -		
MENU	Menu	TOP MENU MENU	Menu		
SOURCE	Source	TIMER AV	AV		
RETURN	Return	RETURN BACK	Back		
EPG	EPG	-/-- GUIDE	Guide		
INFO	Info	DISPLAY INFO	Info		
SLEEP	Sleep	PROG SLEEP	Sleep		
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch		
	Angle / Media	APP MEDIA	Media		
SEARCH MODE	Search Mode	SEARCH TV/R	TV/R		
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info		
PRESETS	Presets	DISC NAV LIST	List		