

Original		Rechange	
POWER	Power		Power
MARKER	Marker	HOME SMART	Smart
OPEN/CLOSE	Open/Close	ZOOM	Eject
SEARCH	Search	SEARCH TV/R	TV/R
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE	Angle	A	Red
RANDOM	Random	APP MEDIA	Media
PROGRAM	Program	PROG SLEEP	Sleep
CLEAR	Clear	CLEAR EXIT	Exit
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7

Original		Rechange	
8	8	8	8
9	9	9	9
0	0	0	0
SKIP I◄◄	I<<	◄◄	I<<
PLAY ►	Play	PLAY MODE ►	Play
SKIP ►►I	>>I	►►	>>I
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
STOP ■	Stop	■	Stop
PAUSE/STEP ❚❚	Pause/Step	❚❚	Pause
DISPLAY	Display	DISPLAY INFO	Info
SLO I◄	<I Slow	◄◄	<<
LOW I►	Slow I>	►►	>>
SELECT/ENTER	Select/Enter	OK	Ok
▲	Up	▲	Up
▼	Down	▼	Down
►	Right	►	Right
◄	Left	◄	Left





Original		Rechange	
MENU	Menu	TOP MENU MENU	Menu
TITLE	Title	DISC NAV LIST	List
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
REPEAT	Repeat	REPEAT TEXT	Text
A-B	A-B	PICTURE FORMAT	Format

Original	Rechange

