Original		Rechange	
POWER	Power	POWER	Power
FUNCTION TV SOURCE	Function Tv	RDS AV INPUT	AV / Input / RDS
EJECT	Eject	SURROUND EJECT	Eject / Surround
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
V-SOUND	V-Sound	LANG I/II AUDIO	Audio / Lang I/II
V-SOUND	V-Sound	SHIFT + TITLE SOUND	Shift + Sound / Title
0	0	HDMI - SAT 0	0
DSP/EQ	DSP/EQ	EQ SUBTITLE	Subtitle / EQ

Original		Rechange	
I<<	I<<	PRESET- I<<	I<< / Preset-
>>I	>>I	PRESET+ >>I	>>I / Preset+
<<	<<	TUNE- <<	<< / Tune-
>>	>>	TUNE+ >>	>> / Tune+
STOP	Stop	HOLD STOP	Stop / Hold
PLAY	Play	SLOW PLAY	Play / Slow
PAUSE	Pause	STEP - FREEZE PAUSE	Pause / Step / Freeze
VOL +	Vol +	VOL +	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TUNING / CH	Tuning/ CH+	SHIFT + TUNE+ >>	Shift + >> /
TUNING / CH	Tuning/ CH+	CH PAGE +	CH+ / Page+
VOL -	Vol -	VOL -	Vol -
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
TUNING / CH	Tuning/ CH-	CH PAGE -	CH- / Page-
TUNING / CH	Tuning/ CH-	SHIFT + TUNE- <<	Shift + << /
DISC MENU	Disc Menu	TOP MENU D.MENU	D.Menu / Top
MENU	Menu	HOME MENU	Menu / Home

Original		Rechange		Original	Rechange
TITLE MENU	Title Menu	TITLE SOUND	Sound / Title		
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /		
▲	Up	▲	Up		
INFO	Info	ANGLE INFO	Info / Angle		
◀	Left	◀	Left		
↵	Enter	OK	OK		
▶	Right	▶	Right		
RETURN	Return	RETURN BACK	Back / Return		
▼	Down	▼	Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
A	Red	NETFLIX SEARCH	Red / Netflix / Search		
TUNER MEMORY B	Green/Tuner	APP REPEAT	Green / APP / Repeat		
MO/ST C	Yellow/MO/ST	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
CD RIPPING D	Blue/CD Ripping	Prime Video RANDOM	Blue / Prime Video / Random		
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer		
S.VOL	S. Vol	LIST SMART	Smart / List		
AUDIO UPSCALE P.BASS	P. Bass/Audio Upscale	MEDIA DISPLAY	Display / Media		

Original		Rechange	
POWER	Power		Power
FUNCTION TV SOURCE	Function Tv	RDS AV INPUT	AV / Input / RDS
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
<<	<<	TUNE- <<	<< / Tune-
>>	>>	TUNE+ >>	>> / Tune+
Stop	Stop	HOLD	Stop / Hold
Play	Play	SLOW	Play / Slow

Original		Rechange	
Pause	Pause	STEP-FREEZE	Pause / Step / Freeze
VOL +	Vol +	VOL +	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TUNING / CH	CH+	CH PAGE +	CH+ / Page+
VOL -	Vol -	VOL -	Vol -
TUNING / CH	CH-	CH PAGE -	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
Up	Up	Up	Up
INFO	Info	ANGLE INFO	Info / Angle
Left	Left	Left	Left
Enter	Enter	OK	OK
Right	Right	Right	Right
RETURN	Return	RETURN BACK	Back / Return
Down	Down	Down	Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
A	Red	NETFLIX SEARCH	Red / Netflix / Search

Original	Rechange	Original	Rechange
TUNER MEMORY B Green	APP REPEAT Green / APP / Repeat		
MO/ST C Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
CD RIPPING D Blue	Prime Video RANDOM Blue / Prime Video / Random		