# Mandis shop

## Pioneer CU-PD046

| Original | Rechange |
|---|---|
| Standby / On | Power |
| Disc 1 | 1 |
| Disc 2 | 2 |
| Disc 3 | 3 |
| Disc 4 | 4 |
| Disc 5 | 5 |
| Disc 6 | 6 |
| Stop | Stop / Hold |
| Pause | Pause / Step / Freeze |
| Play | Play / Slow |
| Random | Blue / Prime Video / Random |
| << | << / Tune- |
| >> | >> / Tune+ |
| Hi-Lite | Smart / List |
| I<< | I<< / Preset- |
| >>I | >>I / Preset+ |
| Program | TV/Radio / Program |

| Original | Rechange |
|---|---|
| Delete | Back / Return |
| Check | OK |
| Clear | Exit / Cancel / Clear |

https://tout-telecommande.fr/fr/Pioneer/1696-950-telecommande-de-remplacement-pour-Pioneer-CU-PD046.html