

Original	Rechange	Original	Rechange
Power	Power	0/10	0
Open / Close	Eject / Surround	10+	Guide / EPG / -/--
Language	Audio / Lang I/II	Prog	TV/Radio /
Angle	Info / Angle	Mute	Mute / Dimmer
Subtitle	Subtitle / EQ	Zoom	Zoom / Size
Time	Sleep / Timer	A-B	Yellow / YouTube / Repeat
Display	Display / Media	Repeat	Green / APP / Repeat
PDVD	Smart / List	Step	Shift + Pause / Step /
1	1	Slow	Shift + Play /
2	2	Return	Back / Return
3	3	Resume	Fav / Marker / PC
4	4	View	AV / Input / RDS
5	5	Ran	Blue / Prime Video / Random
6	6	Vol-	Vol-
7	7	Vol+	Vol+
8	8	Menu	Menu / Home
9	9	Up	Up





Original		Rechange		Original	Rechange
TITLE	Title	TITLE SOUND	Sound / Title		
	Left		Left		
ENTER	Enter	OK	OK		
	Right		Right		
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /		
	Down		Down		
PBC	PBC	GOTO TEXT	Text / Goto		
REV	Rev	TUNE-	<< / Tune-		
FWD	Fwd	TUNE+	>> / Tune+		
PREV	Prev	PRESET-	I<< / Preset-		
NEXT	Next	PRESET+	>>I / Preset+		
L/R	L/R	TOP MENU D.MENU	D.Menu / Top		
N/P	N/P	FORMAT PICTURE	Picture / Format		
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
PLAY	Play	SLOW	Play / Slow		
PAUSE	Pause	STEP · FREEZE	Pause / Step / Freeze		
STOP	Stop	HOLD	Stop / Hold		

