

Original		Rechange	
POWER	Power		Power
MASTER VOLUME	Master Volume	VOL +	Vol+
MASTER VOLUME	Master Volume	VOL −	Vol-
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
SLEEP	Sleep Tuner	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CALL	Call Tuner	RETURN BACK	Back / Return
BAND	Band Tuner	PROGRAM TV/RADIO	TV/Radio /
PLAY	Play Deck B		Right
STOP	Stop Deck B		Left
DIRECTION	<> Deck B	OK	OK
>>	>> Deck B		Up
<<	<< Deck B		Down
REC	Rec Deck B	REC MODE	Rec / Rec Mode
REC MUTE	Rec Mute Deck	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
PLAY	Play Deck A	SHIFT +	Shift + Right
STOP	Stop Deck A	SHIFT +	Shift + Left
>>	>> Deck A	SHIFT +	Shift + Up

Original		Rechange	
<<	<< Deck A	SHIFT +	Shift + Down
PHONO	Phono	NETFLIX SEARCH	Red / Netflix / Search
LD	LD	APP REPEAT	Green / APP / Repeat
VIDEO/AUX	Video/AUX	YouTube REPEAT A-B	Yellow / YouTube / Repeat
DAT	DAT	Prime Video RANDOM	Blue / Prime Video / Random
DIGITAL	Digital	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
/PAUSE PLAY	Play CD	SLOW	Play / Slow





Original	Rechange	Original	Rechange
Stop CD	Stop / Hold		
>>I CD	>>I / Preset+		
I<< CD	I<< / Preset-		
<< CD	<< / Tune-		
Time CD	Picture / Format		
EQ On/Off	Smart / List		
Memo	Zoom / Size		
ENT	Fav / Marker / PC		
Channel	Guide / EPG / -/--		
Level Up	CH+ / Page+		
Level Down	CH- / Page-		
Band Up	Shift + CH+ /		
Band Down	Shift + CH- /		

