Original		Rechange	
POWER	Power	POWER	Power
SOURCE	Source	TIMER AV	AV
HDMI	HDMI	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
0	0	0	0
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
Vol +	Vol +	+ VOL	Vol +
MUTE	Mute	MUTE	Mute

Original		Rechange	
P	PR+	+ CH	Ch +
	Vol -	VOL −	Vol -
CH LIST	CH List	DISC NAV LIST	List
P	PR-	CH −	Ch -
HUB SMART	Smart/Hub	HOME SMART	Smart
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
	Up		Up
INFO	Info	DISPLAY INFO	Info
	Left		Left
OK	Enter	OK	Ok
	Right		Right
RETURN BACK	Return	RETURN BACK	Back
	Down		Down
EXIT	Exit	CLEAR EXIT	Exit
A	Red/A	A	Red

Original		Rechange		Original		Rechange	
B	Green/ B	B	Green				
C	Yel l ow/ C	C	Yel l ow				
D	Bl ue/ D	D	Bl ue				
TV SOCIAL	TV Soci al	PROG SLEEP	Sl eep				
SEARCH	Sear ch	SEARCH TV/R	TV/ R				
3D	3D	ECO 3D	3D				
E-MANUAL	E- Manual	E-MANUAL D.MENU	D. Menu				
D	D	SOUND DUAL	Dual				
AD/SUBT	AD/ Subt	AD SUBT	Subt				
<<		<<	<<				
Pause	Pause	Pause	Pause				
>>		>>	>>				
Rec	Rec	REC MODE	Rec				
Play	Pl ay	PLAY MODE	Pl ay				
Stop	St op	Stop	St op				